

## BOBCAT COMPANY PRICE PAGES NA LOADERS – ALL-WHEEL STEER



**Please note the following when using Bobcat Price Pages:**

- All prices are shown in U.S. dollars.
- Check BobcatNET Pricing Homepage for current Canadian exchange rate.
- To ensure having the correct Part Number for a Dealer Installed Accessory, obtain the loader model and serial number and check with Dealer Parts Department.
- For current Dealer Installed Accessories pricing, reference BobQuote or Dealer Parts Department.
- Prices and specifications are subject to change without notice.

**THE FOLLOWING UPDATES HAVE BEEN MADE TO THIS DOCUMENT:**

04/18/2011	New part numbers for wheel and tire assembly on A770
06/30/2011	Updated select Dealer Installed Accessories.
02/22/2012	Added Interim Tier 4 (iT4) A770, moved Tier 3 A770 to discontinued section.
01/02/2013	H71 Option Package discontinued for the A770.
09/06/2013	Added NEW Dealer Installed Accessories: Lift Cylinder Cushion Piston and Tilt Cylinder Shield Kit
03/23/2015	Added Tier 4 A770, moved iT4 A770 to discontinued section.
05/15/2015	Updated select Dealer Installed Accessories.
07/15/2015	Added Weighlog Attachment
01/01/2016	Effective Friday, January 1 <sup>st</sup> , 2016 Bobcat Company has adjusted the SLP of select options and power units.
10/12/2016	Updated with M2-Series loaders.
04/26/2017	Add Reversing Fan Kit to Dealer Installed Accessories for select loaders.
10/03/2017	Replaced Vinyl Air Ride Seat option with Heated Cloth Air Ride Seat option.
01/01/2017	Added extended warranty to Bobcat engine machines
01/01/2017	Adjusted SLP of machines on January 1 <sup>st</sup> 2018
01/26/2018	Added Rear Camera kit on select loaders
05/01/2018	Effective Tuesday, May 1, 2018 Bobcat Company has adjusted the SLP of select options and power units.
01/01/2019	Discontinued the following options; Severe Duty Tires: R09-C04, Severe Duty Poly Filled: R09-C05

*\*Certain Specification(s) are based on engineering calculations and are not actual measurements. Specification(s) are provided for comparison purposes only and are subject to change without notice. Specification(s) for your individual Bobcat equipment will vary based on normal variations in design, manufacturing, operating conditions, and other factors.*

# A770 (Tier 4) BOBCAT ALL-WHEEL STEER LOADER



## STANDARD EQUIPMENT

- |  |  |
|--|--|
| <p>92 HP Turbo Tier 4 Diesel Engine<br/>                 2-Speed Travel<br/>                 Air Intake Heater (Automatically Activated)<br/>                 Auto Idle Option<br/>                 Auxiliary Hydraulics: Variable Flow<br/>                 Backup Alarm<br/>                 Bob-Tach<br/>                 Bobcat Interlock Control System (BICS™)<br/>                 Controls: Joystick Style with Hand Lever and Foot Pedal for Engine Speed Control<br/>                 Enclosed Cab with Air Conditioning &amp; Heat<br/>                 Engine/Hydraulic Systems Shutdown<br/>                 Dual Steering Modes:</p> <ul style="list-style-type: none"> <li>• All-Wheel Steer Mode</li> <li>• Skid-Steer Mode</li> </ul> <p>Horn</p> | <p>Instrumentation: Engine Temperature &amp; Fuel Gauges, Hourmeter, RPM and Warning Lights<br/>                 Lift Arm Support<br/>                 Lift Path: Vertical<br/>                 Lights, Front &amp; Rear<br/>                 Operator Cab</p> <ul style="list-style-type: none"> <li>• Includes: Adjustable Suspension Seat, Top &amp; Rear Windows, Seat Bar &amp; 3-Point Seat Belt</li> <li>• Roll Over Protective Structure (ROPS) meets SAE-J1040 &amp; ISO 3471</li> <li>• Falling Object Protective Structure (FOPS) meets SAE-J1043 &amp; ISO 3449, Level I; (Level II is available through Bobcat Parts)</li> </ul> <p>Parking Brake – Spring Applied, Pressure Released<br/>                 Power Bob-Tach<br/>                 Tires: 12-16.5, 12 PR, Bobcat Heavy Duty</p> |
|--|--|

## QUICK SPECS

	<b><u>A770</u></b>
Rated Operating Capacity .....	3,325 lbs.
Engine Model .....	3.4L Bobcat Engine
Engine Fuel .....	Diesel
Engine Cooling.....	Liquid
Horsepower .....	92
Hydraulic Pump Capacity-Standard Flow.....	23.0 GPM
Hydraulic Pump Capacity-High Flow (Optional) .....	36.6 GPM
Travel Speed	
• Low Range/High Range.....	7.1/12.3 MPH
• Maximum Reverse .....	7.1 MPH
Operating Weight .....	9,623 lbs.
Shipping Weight.....	8,754 lbs.
Cab Height .....	81.3"
Width (w/out Attachment) .....	74.7"
Length (w/out Attachment) .....	114.3"
Wheelbase .....	48.3"
Reach at Maximum Height .....	31.5"
Height to Hinge Pin.....	132.0"

## A770 (Tier 4)

### BOBCAT ALL-WHEEL STEER LOADER

PART NUMBER	DESCRIPTION	SLP IN US \$
-------------	-------------	--------------

<b>M0287</b>	A770 SKID STEER LOADER (EQUIPPED WITH T4 ENGINE).....	<b>\$74,601</b>
--------------	---	-----------------

AIR CONDITIONED/HEATED CAB PACKAGES		
PART NUMBER	DESCRIPTION	SLP IN US \$

<b>M0287-P01-A91</b>	A91 OPTION PACKAGE .....	<b>\$3,292</b>
<b>M0287-P01-A71</b>	A71 OPTION PACKAGE .....	<b>\$1,387</b>

<u>A71</u>	<u>A91</u>
Cab Accessories Package*	Cab Accessories Package*
Sound Reduction	Sound Reduction
Deluxe Instrument Panel with Keyless Start	Deluxe Instrument Panel with Keyless Start
Attachment Control Kit	Attachment Control Kit
	High Flow Hydraulics
	Hydraulic Bucket Positioning

*\*Cab Accessories Package: Deluxe Headliner with Dome Light, Cab Accessory Harness, Power Port, Lower Interior Panels with Storage Compartments and Cup Holder.*

# A770 (Tier 4) BOBCAT ALL-WHEEL STEER LOADER

PART NUMBER	DESCRIPTION	FACTORY INSTALLED OPTIONS	SLP IN US \$
-------------	-------------	---------------------------	--------------

### Individual Option Requirements

**NOTE:** *The following options may require additional equipment, see details below. If the required equipment is not included in a Cab Package the Bobcat ordering systems will automatically add the equipment to the order.*

**7-PIN ATTACHMENT CONTROL KIT**

**Required** for High Flow Hydraulics. The 7-Pin Attachment Control Kit is included in the A71 and A91 Cab Packages, if one of those Cab Packages is not ordered, you must add ..... **\$245**

### Individual Options

*The options may require additional equipment for operation, see option requirements above for details.*

<b>M0287-R03-C03</b>	<b>HIGH FLOW HYDRAULICS</b> ..... Provides 36.6 GPM and 3500 PSI for attachment operation. The 7 pin attachment control kit is required.		<b>\$2,246</b>
<b>M0287-R11-C02</b>	<b>HYDRAULIC BUCKET POSITIONING</b> ..... Bucket Positioning helps the operator keep the same tilt of the load during lifting. Includes On/Off switch.		<b>\$558</b>
<b>M0287-R05-C11</b>	<b>CLOTH HEATED AIR RIDE SUSPENSION SEAT</b> ..... Includes Heat on/off switch on the back of the seat. Must order an A or O cab package.		<b>\$475</b>
<b>M0287-R26-C02</b>	<b>RADIO</b> ..... Includes weatherproof AM/FM/NOAA Weather Band Radio, Speakers, and Antenna. Works with MP3 or other portable music player. <b>Must order an A Cab Package.</b>		<b>\$498</b>
<b>M0287-R32-C02</b>	<b>REVERSING FAN</b> ..... Temporarily reverses the cooling fan direction to blow dust and small debris from the radiator and rear screens. Includes three operating modes: Automatic, Momentary, & OFF.		<b>\$616</b>
<b>M0287-R33-C02</b>	<b>AUTOMATIC RIDE CONTROL</b> ..... Automatically activates by detecting increased hydraulic lift arm pressure when the loader is carrying material. Includes on/off switch.		<b>\$741</b>

### Tires

*Set of 4 Tires in Place of Base Equipment*

<b>M0287-R09-C04</b>	<b>12-16.5, 12 PR, BOBCAT SEVERE DUTY TIRES [DISCONTINUED]</b> ..... Loader width 74.7"		<b>\$915</b>
<b>M0287-R09-C05</b>	<b>12-16.5, 12 PR, BOBCAT SEVERE DUTY-POLY FILL TIRES [DISCONTINUED]</b> ..... Loader width 74.7"		<b>\$1,802</b>
<b>M0287-R09-C06</b>	<b>33 X 15.5-16.5, 12 PR, BOBCAT SUPER FLOAT TIRES- OFFSET RIMS</b> ..... Loader width 80.4"		<b>\$961</b>
<b>M0287-R09-C12</b>	<b>33 X 15.5-16.5, 12 PR, TURF AND SAND TIRES</b> ..... Loader width 80.4"		<b>\$1,011</b>

## A770 (Tier 4)

### BOBCAT ALL-WHEEL STEER LOADER

PART NUMBER	DEALER INSTALLED ACCESSORIES – ORDER FROM SALES DESCRIPTION	SLP IN US \$
<i><u>Spare Wheel and Tire Assemblies</u></i>		
7202896	12-16.5, 12 PR, BOBCAT HEAVY DUTY TIRE ASSEMBLY - RIGHT ..... Spare Wheel and Tire Assembly	\$394
7202899	12-16.5, 12 PR, BOBCAT HEAVY DUTY TIRE ASSEMBLY - LEFT..... Spare Wheel and Tire Assembly	\$394
7202930	12-16.5, 12 PR, BOBCAT SEVERE DUTY TIRE ASSEMBLY ..... Spare Wheel and Tire Assembly	\$624
7202932	12-16.5, 12 PR, BOBCAT SEVERE DUTY-POLY-FILL TIRE ..... Spare Wheel and Tire Assembly	\$841
7109575	33 X 15.5-16.5, 12PR, BOBCAT SUPER FLOAT TIRE ASSEMBLY - RIGHT ..... Spare Wheel and Tire Assembly	\$630
7109574	33 X 15.5-16.5, 12PR, BOBCAT SUPER FLOAT TIRE ASSEMBLY - LEFT ..... Spare Wheel and Tire Assembly	\$635
7109570	33 X 15.5-16.5, 10 PR, BOBCAT TURF & SAND TIRE ..... Spare Wheel and Tire Assembly	\$646
<i><u>Cab Accessories</u></i>		
7257723	FORESTRY APPLICATIONS KIT- TIER 4..... Kit is required to operate Forestry Cutter and provides operator and machine protection. For kit contents, see Forestry Cutter in Attachments Section. Not compatible with Rear Auxiliary Hydraulics. <b>Must also order Engine Compartment Seal Kit, order from parts.</b> Est. Install time: 6.5 hrs.	\$_____
<b>Note:</b>	Forestry Wiper Kit (P/N 7196560) is available for the Forestry Applications Kit, order from parts.	

# A770 (Tier 4) BOBCAT ALL-WHEEL STEER LOADER

## PART DEALER INSTALLED ACCESSORIES – ORDER FROM PARTS NUMBER DESCRIPTION

*Part numbers for kits in this section are current as of October 2016 and pertain to current loader models as of that date. To ensure having the correct Part Number for a Dealer Installed Accessory, obtain the loader model and serial number and check with Dealer Parts Department. For the most current Dealer Installed Accessories pricing, refer to BobQuote or Dealer Parts Department.*

### Cab Accessories – Enclosures, Doors, Windows

7128393	<b>CAB ENCLOSURE DOOR KIT</b> ..... Includes Front Door with Sensor Switch and Wiper/Washer. Must also order Side Windows Kit to completely enclose cab. Est. Install time: 3.5 hrs.	\$ _____
7186723	<b>FOPS WINDOW KIT</b> ..... Est. Install time: 10 min.	\$ _____
7174127	<b>FORESTRY DOOR KIT</b> ..... Est. Install time: 2 hrs.	\$ _____
7182335	<b>SIDE WINDOW LEXAN KIT</b> ..... Includes 2 Sliding Side Lexan Windows. Est. Install time: 1 hr.	\$ _____
7128342	<b>SLIDING SIDE WINDOWS KIT</b> ..... Includes 2 Sliding Side Windows. Must also order Cab Enclosure Door Kit to completely enclose cab. Est. Install time: 1 hr.	\$ _____
7128395	<b>SPECIAL APPLICATIONS POLYCARBONATE DOOR KIT</b> ..... Provides added operator protection during some attachment applications. Includes ½" thick polycarbonate front door. Must order a Side Windows Kit, Cab Seals Kit and Special Applications Rear Window to completely enclose cab. Est. Install time: 3 hrs.	\$ _____
7128389	<b>SPECIAL APPLICATIONS POLYCARBONATE REAR WINDOW KIT</b> ..... Provides added operator protection during some attachment applications. Includes ½" thick polycarbonate rear window. Must order a Side Windows Kit, Cab Seals Kit and Special Applications Front Door to completely enclose cab. Est. Install time: 0.5 hr.	\$ _____

### Cab Accessories – Heating and Air Conditioning

7252056	<b>AIR CONDITIONING KIT</b> ..... For A770 equipped with Interim Tier 4 Engine. Loader must be equipped with Cab Enclosure with Heater. Est. Install time: 8 hrs.	\$ _____
7128484	<b>HEATER KIT</b> ..... Must also order heater plumbing kit. Est. Install time: 5 hrs. to install heater and plumbing kit	\$ _____
7252058	<b>HEATER PLUMBING KIT</b> ..... Est. Install time: 5 hrs. to install heater and plumbing kit	\$ _____
7200657	<b>LOWER AIR DUCT KIT</b> ..... Includes two air ducts to direct air flow towards the foot well and lower cab door area. Loader must be equipped with Cab Enclosure and Heater or Air Conditioning. Est. Install time: 1 hr.	\$ _____

### Cab Accessories – Other

7174903	<b>CAB SEALS KIT</b> ..... Includes bottom of cab and foot pod area seals. Needed to completely enclose the cab. Est. Install time: 2.5 hrs.	\$ _____
7170782	<b>DELUXE CAB GAS SPRING KIT</b> ..... 3rd gas spring for enclosed cab. Est. Install time: 1 hr.	\$ _____
7156253	<b>DELUXE HEADLINER KIT</b> ..... Includes headliner with light and rear corner cab trim. Est. Install time: 1 hr.	\$ _____
7174171	<b>DELUXE HEATER / AIR CONDITIONING HEADLINER KIT</b> ..... Includes Headliner with interior light, air conditioning/heater vents and rear corner cab trim. Needed to upgrade non-AC/Heater cab to include AC/Heat. Est. Install time: 1 hr.	\$ _____

# A770 (Tier 4)

## BOBCAT ALL-WHEEL STEER LOADER

**PART NUMBER                      DEALER INSTALLED ACCESSORIES – ORDER FROM PARTS**  
**DESCRIPTION**

**Cab Accessories – Other (continued)**

<b>7196560</b>	<b>FORESTRY WIPER KIT .....</b> Loader must be equipped with Forestry Door; Reference P/N 7174127 Forestry Door or 7230523 Forestry Applications Kit for detail. Est. Install time: 1 hr.	\$ _____
<b>7240148</b>	<b>INTERMITTENT WIPER KIT .....</b> Includes intermittent wiper switch, cover, harness and tie straps. Kit allows operator to adjust the speed of the wiper to match the operating conditions. Est. Install time: 1 hr.	\$ _____
<b>7225133</b>	<b>REAR WIPER KIT .....</b> Deluxe Headliner, Cab Accessory Harness, Lower Interior Panels and Front Door with Wiper are required. Wiper is activated by a switch on the rear wiper motor. Est. Install time: 4 hrs.	\$ _____
<b>7172897</b>	<b>RESEAL PLUGS KIT .....</b> Includes plugs to seal cab and frame after the removal of the following: FOPS Kit, Single Point Lift Kit, Four Point Lift Kit, and Backhoe Attachment. Est. Install time: 1 hr.	\$ _____
<b>7172903</b>	<b>WHITE DECAL KIT (CAB TOP) .....</b> Applied to cab top to maintain a cooler temperature inside the operator’s cab. Est. Install time: 0.5 hr.	\$ _____

**Counterweight Kits**

<b>7129250</b>	<b>COUNTERWEIGHT KIT, 200 LBS.....</b> Includes (4) 50 pound weights that bolt to rear uprights of loader. See operator’s manual for ROC increase. Not compatible with the Quick-Tach Water Kit or Rear Stabilizers. Est. Install time: 1 hr.	\$ _____
<b>7129251</b>	<b>COUNTERWEIGHT KIT, 300 LBS.....</b> Includes (6) 50 pound weights that bolt to rear uprights of loader. See operator’s manual for ROC increase. Not compatible with the Quick-Tach Water Kit or Rear Stabilizers. Est. Install time: 1 hr.	\$ _____
<b>7129252</b>	<b>COUNTERWEIGHT KIT, 400 LBS.....</b> Includes (8) 50 pound weights that bolt to rear uprights of loader. See operator’s manual for ROC increase. Not compatible with the Quick-Tach Water Kit or Rear Stabilizers. Est. Install time: 1 hr.	\$ _____

**Electrical Accessories**

_____	<b>ATTACHMENT CONTROL KIT .....</b> For complete listing of Attachment Control Kits, P/N’s and Descriptions – Refer to Attachments Section of the Price Pages.	\$ _____
<b>7128338</b>	<b>FOUR-WAY FLASHER / TURN SIGNAL KIT.....</b> Est. Install time: 1 hr.	\$ _____
<b>7129299</b>	<b>ROTATING BEACON KIT.....</b> Est. Install time: 1 hr.	\$ _____
<b>7129301</b>	<b>STROBE LIGHT KIT, AMBER .....</b> Est. Install time: 1 hr.	\$ _____
<b>7256348</b>	<b>SIDE LIGHT KIT.....</b> Includes two LED side lights Est. Install time: 0.5 hr.	\$ _____

**Engine Accessories**

<b>7218446</b>	<b>DIESEL PARTICULATE FILTER (DPF) REMOTE PARKED REGENERATION KIT.....</b> For A770 equipped with Interim Tier 4 Engine. Allows operator to perform a parked regeneration if too much soot is allowed to accumulate in the DPF. Est. Install time: 1 hr.	\$ _____
<b>7221486</b>	<b>DIESEL PARTICULATE FILTER (DPF) INHIBIT SWITCH KIT.....</b> For A770 equipped with Interim Tier 4 Engine. Est. Install time: 0.25 hr.	\$ _____
<b>7239665</b>	<b>ENGINE BLOCK HEATER KIT.....</b> Est. Install time: 0.25 hr.	\$ _____

# A770 (Tier 4)

## BOBCAT ALL-WHEEL STEER LOADER

PART NUMBER	DEALER INSTALLED ACCESSORIES – ORDER FROM PARTS DESCRIPTION	
-------------	---	--

**Hydraulic Accessories**

<b>7128442</b>	<b>HYDRAULIC BUCKET POSITIONING KIT</b> ..... Bucket Positioning helps the operator keep the same tilt position of the load during lifting. Includes on/off switch. Est. Install time: 3 hrs.	\$ _____
<b>7207408</b>	<b>LIFT CYLINDER CUSHION PISTON</b> ..... Softens the contact between the lift arms and mainframe reducing noise. Must also order Piston Nut p/n 6810540.	\$ _____
<b>7268419</b>	<b>REAR AUXILIARY HYDRAULIC KIT</b> ..... Est. Install time: 10 hrs.	\$ _____

**Instrumentation**

<b>7213928</b>	<b>DELUXE INSTRUMENT PANEL WITH KEYLESS START</b> ..... Includes keyless start, feature lockouts, help screens, clock, job clock, system diagnostic capability and more. Est. Install time: 1 hr.	\$ _____
<b>7213929</b>	<b>KEYLESS START PANEL KIT</b> ..... Allows operator to start the loader by entering a reprogrammable number code. Est. Install time: 1 hr.	\$ _____

**Lift Kits**

<b>7156605</b>	<b>FOUR-POINT LIFT KIT</b> ..... Cannot be used on loaders equipped with Backhoe Mounting Kit. Est. Install time: 2 hrs.	\$ _____
<b>7226713</b>	<b>SINGLE POINT LIFT KIT</b> ..... Est. Install time: 3 hrs.	\$ _____

**Loader Guard Kits**

<b>7190789</b>	<b>ENGINE COMPARTMENT SEAL KIT</b> ..... Required when using M-series 700 Platform machines with forestry cutters. Kit includes cab/mainframe seal, tailgate seal, mainframe slot covers and lift cylinder boots. Est. Install time: 2 hrs.	\$ _____
<b>7129293</b>	<b>FOPS KIT</b> ..... Additional shield assembly for cab top. Meets ISO 3449, Level II Requirements. Est. Install time: 1.5 hrs.	\$ _____
<b>7257724</b>	<b>REAR WORK LIGHTS GUARD KIT</b> ..... Est. Install time: 0.5 hr.	\$ _____
<b>7174129</b>	<b>FRONT WORK LIGHTS GUARD KIT</b> ..... Est. Install time: 0.5 hr.	\$ _____
<b>7174130</b>	<b>MUFFLER GUARD KIT</b> ..... Est. Install time: 0.25 hr.	\$ _____
<b>7250844</b>	<b>COUPLER GUARD KIT</b> ..... Must also order Installation Instructions p/n 6987492. Est. Install time: 5 min.	\$ _____
<b>7203665</b>	<b>REAR BUMPER KIT</b> ..... Includes bolt-on Rubber Bumper and mounting hardware. Helps protect the rear of the loader from damage due to scraping or contact with objects in tight places. Est. Install time: 1 hr.	\$ _____
<b>7187059</b>	<b>TILT CYLINDER SHIELD KIT</b> ..... Est. Install time: 0.5 hr.	\$ _____

**Power Bob-Tach Kits**

<b>7310665</b>	<b>POWER BOB-TACH KIT</b> ..... Must also order Power Bob-Tach Plumbing Kit. Est. Install time: 4 hrs. to install Power Bob-Tach Kit and Plumbing Kit	\$ _____
<b>7310805</b>	<b>POWER BOB-TACH PLUMBING KIT</b> ..... Est. Install time: 4 hrs. to install Power Bob-Tach Kit and Plumbing Kit	\$ _____

**Radio**

<b>6988435</b>	<b>RADIO KIT</b> ..... Includes weatherproof AM/FM/NOAA Weather Band Radio, Radio Mounting Bracket, Speakers, Antenna, and Installation Hardware. Works with MP3 or other portable music player. Est. Install time: 3 hrs.	\$ _____
<b>6676108</b>	<b>RADIO HEADPHONES</b> .....	\$ _____



## A770 (Tier 4) BOBCAT ALL-WHEEL STEER LOADER

### PART                                      DEALER INSTALLED ACCESSORIES – ORDER FROM PARTS NUMBER                                      DESCRIPTION

#### Rear Camera Kit

**7329670                      REAR CAMERA KIT** ..... \$ \_\_\_\_\_  
 Includes camera, display and required parts for complete installation.  
 Est. Install time: 4 hrs

#### Remote Control Kits

**7185234                      LOADER RADIO REMOTE CONTROL KIT** ..... \$ \_\_\_\_\_  
 Allows an operator to start/stop the engine, operate the drive system and control the lift, tilt and auxiliary hydraulic functions remotely using a Radio Transmitter. The operator must maintain visual contact with the loader and the loader’s path of travel. Available for loaders equipped with Selectable Joystick Controls (SJC) or All Wheel Steer Loaders. Requires version 57 software or newer.  
 Est. Install time: 0.5 hr.

**6986516                      LOADER RADIO REMOTE OPERATOR TRAINING KIT**..... \$ \_\_\_\_\_

#### Reversing Fan Kits

**7307658                      REVERSING FAN KIT** ..... \$ \_\_\_\_\_  
 Temporarily reverses cooling fan direction to blow dust and small debris from the radiator and rear screens. Includes three operating modes: Automatic, Momentary and OFF. Cab Accessory Harness is required, see Cab Accessory Harness & Lower Interior Panels kit for details. Est. Install Time: 3 hrs.

#### Ride Control Kits

**7300393                      RIDE CONTROL KIT - MANUAL** ..... \$ \_\_\_\_\_  
 Provides a smoother ride by cushioning the lift arms when traveling over rough terrain.  
 Est. Install time: 1.5 hrs.

**7306402                      RIDE CONTROL KIT - AUTO**..... \$ \_\_\_\_\_  
 Provides a smoother ride by cushioning the lift arms when traveling over rough terrain. Includes on/off switch inside of cab.  
 Est. Install time: 1.5 hrs.

#### Seats & Seat Belts

**7129303                      SEAT BELT KIT-3"** ..... \$ \_\_\_\_\_  
 For use with Suspension Seat only. Includes 3" retractable lap belt.  
 Est. Install time: 0.5 hr.

**7128405                      SEAT BELT KIT, 3-POINT** ..... \$ \_\_\_\_\_  
 For use with Suspension Seat only. Includes 2" shoulder belt and 2" lap belt.  
 Est. Install time: 0.5 hr.

**7169480                      SEAT BELT KIT-3", 3-POINT.** ..... \$ \_\_\_\_\_  
 For use with Suspension Seat only. Includes 2" shoulder belt and 3" lap belt.  
 Est. Install time: 0.5 hr.

**7128524                      SUSPENSION SEAT** ..... \$ \_\_\_\_\_  
 Vinyl material. Must also order a seat belt kit unless previously equipped with suspension seat.  
 Est. Install time: 1 hr.

**7183366                      SUSPENSION SEAT, AIR RIDE** ..... \$ \_\_\_\_\_  
 Vinyl material. Must also order a seat belt kit unless previously equipped with suspension seat.  
 Est. Install time: 1 hr.

**7312807                      CLOTH HEATED AIR RIDE SEAT** ..... \$ \_\_\_\_\_  
 Includes Heat on/off switch on the back of the seat. The seat is not compatible with M-Series loaders and select M2-Series loaders. See Dealer Parts Department for the correct M2-Series loader serial number breaks.

#### Sound Reduction Kits

**7172901                      SOUND REDUCTION KIT** ..... \$ \_\_\_\_\_  
 Includes insulating materials and a hydraulic muffler to reduce sound levels at the operator’s ear and for bystanders.  
 Est. Install time: 2 hrs.

**7192148                      DELUXE SOUND KIT FOR SJC CONTROLS**..... \$ \_\_\_\_\_  
 Includes foot pod insulating materials to reduce sound levels at the operator’s ear.  
 Est. Install time: 1 hr.

# A770 (Tier 4) BOBCAT ALL-WHEEL STEER LOADER

## PART DEALER INSTALLED ACCESSORIES – ORDER FROM PARTS NUMBER DESCRIPTION

### Training Kits

<b>6901726</b>	BOBCAT LOADER OPERATOR TRAINING KIT .....	\$ _____
<b>6900641</b>	BOBCAT LOADER SERVICE TRAINING KIT .....	\$ _____
<b>6904762</b>	BOBCAT OPERATOR SAFETY DVD .....	\$ _____
	Includes all of the 10-minute operator safety videos in both English and Spanish.	

### Other Accessories

<b>7257437</b>	AIR DEFLECTOR KIT .....	\$ _____
	Est. Install time: 0.5 hr.	
<b>7129307</b>	FIRE EXTINGUISHER KIT .....	\$ _____
	Est. Install time: 0.5 hr.	
<b>7257869</b>	LOADER WEIGHLOG SCALE KIT .....	\$ _____
	Measures hydraulic pressure at a specific position during the lifting cycle for either static or dynamic weighing. The weighlog kit is not a certified scale. Please see Bobcat Parts Sales & Merchandising Manual for additional details.	
	Est. Install time: 4 hrs.	
<b>7023550</b>	LOCKING FUEL CAP .....	\$ _____
	Includes a Black Locking Fuel Cap that is keyed the same as the loader. Key is Not included. Additional locking fuel cap options are available through parts.	
<b>7128403</b>	TAILGATE LOCK KIT .....	\$ _____
	Est. Install time: 0.5 hr.	

## Discontinued Models

The following models has been discontinued and is no longer available: A770 (iT4), A770 (Tier 3).  
Check dealer inventory for availability.